



#### **Accessories**


Vertical-corner: install by using stainless-steel nails as shown in the illustrations.




















Exclusive Distributor: **Interra USA,Inc.**Location: 981 Powell Ave SW #115 Renton, WA 98057 USA
Tel: 425-277-7850 Fax: 425-277-7410

JOTO TECHNO Co.,Ltd.

## Joto

28 guage Galvanized Steel

# **Installation Manual**

for Joto-Vent Architectural-covering


Joto-Vent System Foundation Vent System



<sup>\*</sup>Before installing the products, read this Installation Manual carefully in order to install them properly.

#### **Table of Joto-Vent Architectural-covering members**

Packing contents		
Product No.	Remarks	Package
WACF-U45	Main body 10 ft. in length	10pieces/box
WACF-U45CO	Outside-corner	5pieces/box
WACF-U45CI	Inside-corner	5pieces/box
WACF-U45JC	Joint-cover	20pieces/box
WACF-U45EC	Endcap	5sets/box
WACF-U45VC (R/L)	Vertical-corner (Right/Left)	10sets/box



JOTO TECHNO Co.,Ltd.

#### Installation procedures

Install the Architectural-covering per the following instructions and illustrations.

#### **WARNING**

- Wear appropriate protective gear such as gloves, hard hats, and protective glasses while at work. Use appropriate cutting tools. Never use inappropriate tools for cutting purpose such as sander to cut by friction.
   Properly handle the tools per their manufacturers' operations manual.
- Provide necessary personnel and equipment to ensure safety transportation
  of the products. In particular, lengthy items must be carried by an
  appropriate number of people. If it must be carried by one person, keep it in
  balance by holding at the center point. Not doing so may lead to personal
  injury or property damages.
- Do not throw or drop the products. Do not step on the products or put anything on them. Doing so may lead to personal injury or property damages.
- Be careful about sharp corners and edges of the products. In particular, be careful not to cut your hand or other body parts with a sharp edge of the products once it has been cut to length.
- Never burn, eat, or let children play with the products. Doing so may lead to serious accidents.

#### **CAUTION**

- Avoid storage under very high or very low temperatures. Do not store the products outdoors. Do not keep the products upright. Doing so may lead to deformation of the products.
- Store the products on a flat surface.
- Never draw out the products from a small opening of a package. Doing so may damage the products.
- Do not block the ventilating holes when you paint the products. Doing so may impair the ventilation performance.
- Avoid using in contact with chemical-treated woods, CCA containing copper, lead, etc. and fire-retardant timbers when using the products, as there is a chance of corrosion when in contact with these types of treated woods. Also, avoid joining the products with fittings or accessories using dissimilar metals such as copper, lead, and alloys.
- Do not use the products at coastal areas (potential damage by seawater) or dense fog-prone areas. This product is a painted galvanized steel, however extreme salty costal air can cause corrosion.
- Drip water caused by exhaust fumes from car or chimney may peel off the paint and coating.
- Remove the plastic film protective sheets on the overlap space of joint before installation.


#### NOTICE

Use stainless-steel nails to install the Architectural-covering.

Remove the plastic film protective sheets on the Architectural-covering immediately after installation.

#### **Combination of Joto-Vent and Architectural-covering**


Install the Architectural-covering by using stainless-steel nails, at an interval of 1.5 ft., over OSB or plywood (outside). The installation should be made at the position where the top of the Architectural-covering comes at 1-3/4 inch (45 mm) above the top surface of the Joto-Vent.




### **Accessories**


Optional materials must be selected from our specified products. Refer to CAUTION and NOTICE for handling precautions.


Outside-corner: install by using stainless-steel nails as shown in the illustrations.







**Inside-corner:** install by using stainless-steel nails as shown in the illustrations.





**Joint-cover:** install by using stainless-steel nails as shown in the illustrations.





Endcap: install by using stainless-steel nails as shown in the illustrations.

